



NOTES:

- ① JSM 200
- ② CONCEALED CLIP
- ③ TAPE SEAL
- ④ EXTENDED EAVE
- ⑤ CONTINUOUS CLEAT

- 1. INSTALL CONTINUOUS CLEAT.
- 2. FASTEN EXTENDED EAVE TRIM AT TOP AND PLACE SEAM SEAL.
- 3. POSITION PANEL.
- 4. FIELD FOLD PANEL END AROUND EXTENDED EAVE.
- 5. INSTALL CLIPS AND PLACE NEXT PANEL.
- 6. HAND TONG SEAM AT CLIPS, USE ELECTRIC SEAMER TO CLOSE SEAM.

ARCHITECTURAL BUILDING COMPONENTS  
 11625 N. HOUSTON ROSSLYN RD.  
 HOUSTON, TX. 77086  
 (281) 931-3986 OR (800) 423-1105  
 FAX: (281) 931-3989  
 www.archmetalroof.com

DETAIL:  
 ISOMETRIC AT EAVE

PANEL TYPE:  
 JSM ROOF SYSTEM

DATE:  
 10-10-02

DETAIL #:  
 J2-3